







We've made a handy video version of this fitting guide, just click the play button to view it.


If you prefer to print the instructions or simply to follow step-by-step, just keep reading.

Assembling the frame

Unpack the blind and frame (the side and bottom frames are packed separately in the same box), then lay out all the parts and push the control chain to one side so it doesn't get tangled.









Installation Guide


PerfectFIT Roller Blinds


Securing the operating chain


2

Gently pry the screw cap from the chain runner, then unscrew and slide off the outer part of the runner. Hook the chain over the exposed runner.

Slide the outer part of the runner back into place and reinsert the screw and screw cover.









Installing the brackets

3






Locate the correct position for the brackets by holding a credit card or store card vertically in the corner of the glass - the bracket will sit in line with the edge of the card.

Installing the blind

4

Line the assembled blind up with the brackets so that the centre prong of the bracket is aligned with the oval slot on the frame. Ensure that the frame is sitting on the inside edge of each of the brackets (between the bracket and the glass).



Push the frame towards the window until the oval slots lock onto the prongs of each of the brackets. The installation of the blind is now complete.

