

## Before you begin



The front roller blind is the highest and closest to you, so make sure that when marking the place where you will place the brackets, the rounded part of the bracket is pointing downwards.


# **Fitting the brackets**

The brackets offer three methods of installation:




**Top-Fixing** 

Where the brackets are screwed into the lintel (or 'ceiling' of the recess)



**Face-Fixing** 

Where the brackets screw into a facing surface (a wall or window frame)



Side-Fixing

Where the brackets are screwed into the side walls of the recess






# **Installation Guide**


# SmartView Electric Double Roller Blinds

### Fitting the blind






Install the rear blind first. Begin by placing the spring-loaded pin into the lower cross-shaped hole on the bracket. Push the blind toward the bracket so the spring-loaded pin depresses.



Keeping the pin depressed, lift the motor end of the blind upwards so the blind is level. Slot the pegs of the on the end of the motor into the cross section of the bracket.



Repeat the process for the front blind, placing the pin into the cross-shaped hole on the bracket and lifting the motor side up to slot into top the cross section.

Once your blinds are installed we recommend plugging in the motor for each, to allow it to fully charge before use. Plug the charging cable (included) into the motor charging port and allow to charge until the LED on the charger plug turns green.





On the front of the swing tag that comes with each blind, you'll find a handy QR code you can scan with your phone. Scan this to download the SmartView app - you'll be setting up your blinds in moments!



#### Top Tip

When scanning your blinds into the app, each blind from a pair will be scanned separately.

You may find it helpful to name your blinds in such a way that it's obvious which blinds are part of which pair.

